Fanvil

V1.1



H1-2 Wire

Quick Installation Guide

Fanvil Technology Co., Ltd
www.fanvil.com

English (EN)

Precautions

Warning: Please do not power cycle the device during system boot up or firmware upgrade. You may corrupt firmware images and cause the unit to malfunction.
Warning: Use only the power adapter included in the device package. Using an alternative non-qualified power adapter may possibly damage the unit.

Overview

The H1-2 Wire phone upgrades the power supply and network connection method based on the original IP phone, using a 2-Wire connection. It features high-definition voice, fast deployment, 2 SIP accounts, support for 2-Wire power supply and network, 8 programmable keys, and other rich functions. It can meet various application scenarios and provide users with high-quality experience.

Packaging list



Keys description



Device installation

Please follow the instructions in below picture to install the device.

- **Bracket desktop installation**



- **Wall mounting (wall stand need buy separately)**



- **Connecting to the device**

Please connect power adapter,2-wire, handset, and to the corresponding ports as described in below picture.

① 2-Wire port: connecting the 2-Wire interface.
② Power port: connect the power adapter.
③ Handset port: connect IP Phone handset.



Network connect

Powered and networked through 2-wire

1. Turn on the power of the 2-Wire PoE switch, and connect the phone's 2 -Wire interface to the 2-Wire PoE switch using a 2-wire cord.
2. The default is DHCP mode.

Phone configuration

Configuration via web

1. Get the IP address from the phone: Press the"#" key for more than 6 seconds to broadcast IP.
2. Login: Input the IP address in the web browser, The PC and phone should be in the same IP address segment(The default username and password are both "admin"
3. Configure: Select network/Account, etc. And fill the relevant content.
4. Save the configuration.

Making a call

1. **Pre-dialing**: enter the phone number and pick up the handset.
2. **Direct dialing**: lift the handset and enter the phone number.
3. **Handsfree**: enter phone number and press or vice versa.
4. **Memory key**: press memory key.

Accepting a call

1. **Using the handset** : pick up the handset.
2. **Using the handsfree** : press .

Redial

1. Press key, redial a call number.

Note: You can contact your service provider for additional settings that may be necessary to con-figure the phone, or download the user manual and FAQ for more detailed information.

Regulatory Compliance

Federal Communication Commission (FCC) — USA

This device complies with Part 15 of FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received; including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in residential installation. This equipment generates, uses, and can radiate radio frequency energy, and if it is not installed and used in accordance with the instruction manual, it may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Fanvil Technology Co., Ltd
Website: www.fanvil.com
EMail: sales@fanvil.com support@fanvil.com
Tel: +86-755-2640-2199 Fax: +86-755-2640-2618
Add: 10/F Block A, Dualshine Global Science Innovation Center, Honglang North 2nd Road, Bao'an District, Shenzhen, China